



Disassembling Sony Ericsson w600i Battery Cover

Removing the battery cover allows access to the battery and back housing fasteners.

Written By: Beau Blanchard



Step 1 — Battery Cover



- Grip the lower portion of the back of the phone and slide downwards.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 09:42:47 AM.